

# INSTALLATION AND SERVICING INSTRUCTIONS **6.6 DURAMAX BYPASS SYSTEM** 2016 AND EARLIER KIT FKDMX66

#### **IMPORTANT NOTICE**

### **Please Note - Before Installation**

Follow the precautions below for optimal product performance and to reduce the risk of property damage, personal injury, and/or death.

## **Read All Instructions Before Proceeding**

If you are uncomfortable with the instructions or have questions, do not attempt installation. Consult a mechanic or contact our customer service department at 800-341-6516 with any additional questions.

Improper installation of this product may result in damage to the vehicle on which it is installed. For questions regarding installation, contact Frantz customer service at 1-800-341-6516.

### **Install On Cool Engine**

Never work in the engine compartment with the engine running. It is advised that you perform a full oil change with installation of this system.

## A. BEFORE YOU BEGIN

- 1. Confirm all items on the Parts List are included in the system.
- 2. Ensure you have the required tools for the job.

#### RECOMMENDED TOOL LIST

- · Drill
- · 7/32" Drill bit for mounting screws
- · 3/8" Socket and wrench for mounting bolts
- · 3/8" Wrench for mounting screws
- · 7/16" Wrench for male hose fitting
- · Utility knife to cut hose and hose coverings
- · 1-1/2" Socket
- · Common screw driver for hose clamps

PARTS LIST				
6.6L Duramax Frantz Filter Kit (FKDMX66)				
Item	Description	Qty.	Part No.	
1.	Mounting Screws with washers	3	FSCR	
2.	Base Gasket	1	KBGA	
3.	Black Knob	1	KBLK	
4.	V-Band Clamp	1	KVCLAMP	
5.	Mounting Bracket	1	KMOU	
6.	Cellulose Filter Media	1	FFMD-SP	
7.	Polished Canister w/Decal	1	KCANP	
8.	Pull Ring	1	KPUL	
9.	Filter Base	1	KBAS	
10.	8' Hose	1	FHOS	
11.	8' Hose Covering	1	FHOS-COV	
12.	Male Hose Fittings	4	FMAL	
	(1/4" Hose Barb)			

Parts List (Cont.)				
Item	Description	Qty.	Part No.	
13.	Hose Clamps	4	F0ET	
14.	90° Brass Elbows	2	FELB90	
15.	45° Brass Elbows	2	FELB45	
16.	Spare Gasket	2	KGBA	
17.	Thread Seal Package	2	FTHR	
18.	Large Adapter	1	FLAD	
19.	Large Adapter Gasket	1	FLADGA	
20.	Adapter Nut	1	FNUT1316	
21.	Bushing	1	FBUS14	
22.	Quick Disconnect - Female	1	FPDC-F	
23.	Quick Disconnect - Male	1	FPDC-M	
24.	Duramax Oil Fill Cap w/O-Ring	1	FPFC-DMX	
25.	5/16 SS Nut	2	FNUT516	
26.	5/16 x 3/4 SS Bolt	2	FBOLT	
27.	5/16 SS Lock Washer	2	FLW516	

**Note:** Be sure to use thread sealer at all connections. This is most important for connections with dissimilar metals (i.e. brass to aluminum).

### **INSTALLATION INSTRUCTIONS**

(some parts for kit may be preinstalled)

## MAKE SURE YOU USE THREAD SEAL (FTHR) ON THE THREADS.

- 1. Locate a good mounting point for the filter. Mount the filter in a place that the hoses will be easy to reach and will not kink. You need enough room to easily separate the canister from the base to replace the filter media. Your kit comes with (3) screws (FSCR) that attach the mounting bracket (KMOU) to the surface you choose. Drill holes with 7/32" drill bit. Use mounting bracket (KMOU) for template for hole layout. The filter base (KBAS) will attach to the bracket with the (2) Nut, bolt, and lock washer combos (FNUT215, FBOLT, FLW516) found in your hardware bag.
- 2. Screw bushing (FBUS14) into the adapter ring (FLAD), and screw your hose fitting (FMAL) into the bushing. (45 or 90 degree Brass elbow may be needed to ensure clearance for hose routing.) This will be the pressure feed for your Frantz Oil Filter.
- 3. Remove your OE spin on filter.
- 4. Match up your adapter ring (FLAD) where the filter came off; there is no need to lubricate the gasket on the bottom of the adapter. The adapter nut (FNUT1316) packaged with the ring will fit in the center hole of the adapter and screw onto the existing OE filter mounting threads. Position adapter ring port in the direction that is best for routing the hoses. Tighten to snug, but not overly tight.
- 5. Your kit includes a replacement aluminum oil fill cap with a Threaded port already in it (FPFC-DMX). Replace OE cap with Frantz cap, but do not throw away OE cap.

- 6. Thread the 90 or 45 degree brass fitting in the top of the cap. (Use the one that provides the best hood clearance.)
- 7. Thread the male guick disconnect (FPCD-M) into brass fitting on oil fill cap.
- 8. Thread Male Hose Fitting (1/4" Hose Barb) into female quick disconnect (FPDC-F). This will be used to connect your oil return line to the oil fill cap (FPFC-DMX).
- 9. Connect both quick disconnects together. (Should hear a click)
- 10. Cut hose (FHOS) to length, and route. Be sure to not run hoses close to or touching any hot exhaust parts or moving parts such as pulleys and belts. Use zip ties to secure if necessary - not included.
- 11. Attach hose to adapter ring fitting (FLAD) using hose clamp. Attach hose to hose fitting on female quick disconnect (FPDC-F) using clamp (FOET).
- 12. The pressure feed line from the oil filter adapter (FLAD) will hook up to the fitting on the center of the filter base bottom labeled "IN," and the return line will hook up to the fitting on the edge of the filter base labeled "OUT". Insert fittings (FMAL) into "In" and "Out" ports on the base. (Brass 45 degree fittings (FELB45) may be used for clearance) Slip hose clamps (FOET) over hose leading from pressure feed; push hose onto "In" fitting. Slip hose clamp over hose leading from oil return and push hose onto "Out" fitting. Tighten clamps.
- 13. Install factory OE. Spin on oil filter to adapter (FLAD). Tighten to OE specs.
- 14. Installation is now complete please follow start up procedures (Section C).

## **C. START UP PROCEDURES**

- 1. Check that all fittings and hoses are securely attached. and that the hoses are routed properly.
- 2. Check engine oil level. Fill to full mark on engine dipstick.
- 3. With the equipment secured start the engine and immediately check oil pressure. NOTE: Pressure may initially take a moment or two to rise. Let your engine run for a minimum of five minutes after installation. This allows your new Frantz Filter to begin absorbing oil in the media and fill the hoses.

Caution: carefully check for leaks at fittings, hoses and mount. If leaks are observed, STOP ENGINE IMMEDIATELY, repair leaks and continue.

- 4. After engine has been ran for a minimum of five minutes, shut off and re-check engine oil level. Fill as necessary.
- 5. Install black hose covering (FHOS-COV) on hoses
- 6. Record vehicle mileage/operating hours and date of installation.

## **D. PERIODIC MAINTENANCE**

1. Inspect the fittings and hoses. Check for leaks, hose deterioration and cuts. Repair and/or replace as necessary. (At minimum at every oil change or 3000 miles whichever occurs first)

2. Filter media should be changed when engine oil is up to operating temperature and the filter housing is not warm. (This indicates oil is no longer flowing through the filter)

## E. CHANGING THE FILTER ELEMENT

**Caution:** Engine should be cold when changing the filter element.

To change the bypass filter element:

- 1. Ensure the engine is off and use caution as the engine, oil and filter may be hot and can result in personal injury. (Let engine cool down, or start with cold engine.)
- 2. Loosen the black knob on the clamp and remove the clamp from the unit.
- 3. Pull filter housing off the filter base.
- 4. Grab pull ring to remove old filter from the canister, dispose of properly.
- 5. Clean out the Canister with a lint free rag and inspect filter base gasket, replace if any cuts or imperfections are found. Make sure gasket is sitting correctly in the receiver groove and coat with clean motor oil.
- 6. Install the new filter media with pull ring in the filter. Install canister back o n filter base.
- 7. Install V-Band Clamp on base. Tighten Clamp using black
- 8. Check oil level and refill as needed.
- 9. Start the engine and check for leaks. (Run engine a minimum of 5 minutes)
- 10. Stop engine
- 11. Check oil level and refill as needed.
- 12. Record date of installation and miles/hours of the unit.

## THE FRANTZ WARRANTY AND GUARANTEE

### The Frantz Warranty

Frantz will replace any part or component that proves defective within 90 days. It will be replaced free of charge (no cost for labor) within that period.

NOTE: If an oil line fails, or an oil leak develops in the Frantz (either through failure of a part, sabotage, incorrect installation, or faulty servicing of the unit), and the engine loses its oil supply, Frantz disclaims any responsibility for damage to the engine should it be operated without proper lubrication.

Every vehicle has either a pressure gauge or warning light to indicate that oil pressure is not sufficient to lubricate the engine. When this occurs, it is the responsibility of the driver to stop the vehicle, investigate the problem, and take whatever remedial action is necessary.

### **The Frantz Guarantee**

Frantz unconditionally states that if the Frantz has been installed and serviced in accordance with the manufacturer's instructions, the filter will keep the oil in your vehicle analytically clean. If it fails to do so, the purchase price of the unit will be refunded by the manufacturer, provided the filter, all parts and the original sales receipt are returned to Frantz. (Customer responsible for shipping cost back to manufacturer.)

PARTS IDENTIFICATION Pages 3 - 6				
NAME	SKU	QTY	VISUAL	
Mounting Screws with washers	FSCR	3		
Base Gasket	KBGA	1		
Black Knob	KBLK	1		
V-Band Clamp	KVCLAMP	1		
Mounting Bracket	KMOU	1	· ·	
Cellulose Filter Media	FFMD-SP	1	Fantz	
Polished Canister w/Decal	KCANP	1	Parent or market	
Pull Ring	KPUL	1		

PARTS IDENTIFICATION Pages 3 - 6			
NAME	SKU	QTY	VISUAL
Filter Base	KBAS	1	
8' Hose	FHOS	1	
8' Hose Covering	FHOS-COV	1	
Male Hose Fittings (1/4" Hose Barb)	FMAL	4	
Hose Clamps	FOET	4	
90° Brass Elbows	FELB90	2	
45° Brass Elbows	FELB45	2	
Spare Gasket	KGBA	2	

PARTS IDENTIFICATION Pages 3 - 6			
NAME	SKU	QTY	VISUAL
Thread Seal Package	FTHR	2	APPLY TO ALL FIRMS TO THE POST OF THE POST
Large Adapter	FLAD	1	
Large Adapter Gasket	FLADGA	1	
Adapter Nut	FNUT1316	1	
Bushing	FBUS14	1	
Quick Disconnect Female	FPDC-F	1	
Quick Disconnect Male	FPDC-M	1	
Duramax Oil Fill Cap w/O-Ring	FPFC-DMX	1	

PARTS IDENTIFICATION Pages 3 - 6			
NAME	SKU	QTY	VISUAL
5/16 SS Nut	FNUT516	2	
5/16 x 3/4 SS Bolt	FBOLT	2	Control of the second s
5/16 SS Lock Washer	FLW516	2	0